


	<p><b>700 Fathom Contour Line -</b> All portions of the cables from the shore to a distance of at least 1km seaward of the 700-fathom line must be buried</p>		<p><b>Existing Cables &amp; Shore Stations -</b> NOAA charted Submarine Cables, 2015.</p>
	<p><b>National HAPC Rocky Reefs -</b> Rock Reefs and Rocky Outcrop areas where 100% of cable burial may not be possible.</p>		<p><b>50 and 25 Kilometer Grid -</b> To aid in spacing out network configurations.</p>



Early Warning Offshore Cascadia  
[cascadia.washington.edu](http://cascadia.washington.edu)

